



Nikon, Type 1 LENS PORT/ GEAR CHART

for Nikon D2x, D40x, D100, D70/s & Fuji S2 pro

NIKON LENS	PORTS	Port EXTENSION	Dome Shade	FOCUS & ZOOM GEAR
10,5 mm f/2,8 G Ed AF DX	18405		18480	(F)18699
14mm f/2.8D ED AF	18405		18480	(F)18693
16mm F2.8 D AF	18405		18480	(F)18689
18mm F2.8 AF	18405	18456	18482	(F)18680
20mm F2.8 AF	18405		18482	(F)18674
24mm F2.8 D AF	18405		18482	(F)18686
28mm F2.8 D AF	18405		18482	(F)18686
60mm F2.8 AF (*1)	18426			(F)18670/(Z)18682
105mm F2.8 AF (*2)	18426	18453		(F)18679/(Z)18683
105MM f/2.8 G ED-1F AF-S VR, NEW	18426	18453		(F)18712
200mm F4 D AF	18426	18454		(F)18656
12-24mm f/4G IF-ED AF-S DX	18405	18456	18480	(F)18695/(Z)18696
17-35mm f/2,8D IF-ED AF-S	18405	18457	18482	(Z)18690
17-55MM f/2.8 ED-IF	18405	18457	18482	(Z)18711
18-35mm f/3.5-4.5 D IF ED AF	18405	18453	18482	(Z)18694
18-55mm f/3.5-5.6G ED II	18405	18463	18482	(Z) 18718
18-70 mm 1:3,5-4,5 G ED (*3)	18405	18453	18482	(Z)18696
20-35mm FR2.8 D AF (*3)	18405	18453	18482	(Z)18675
28-70mm F3.5-4.5 D AF (*3)	18405	18455	18482	(Z)18673
28-85mm F3.5-4.5 AF (*3)	18405	18455	18482	(Z)18675
24-50mm F3.3-4.5 D AF (*3)	18405	18455	18482	(Z)18673
70-180 mm f/4.5-5. 6D ED AF	18426	18454		(F)18691/(Z)18692

(*1) Auto/manual focus selector available 18682

(*2) Auto/manual focus selector available 18683

(*3) +3 diopter needed

SIGMA & TOKINA LENS	PORTS	Port EXTENSION	Dome Shade	FOCUS & ZOOM GEAR
Sigma 10-20mm F4-5.6 EX DC HSM	18405	18456	18480	(Z)18698
Sigma 14mm F2.8 EX ASPHERICAL HSM	18405	18462	18480	(F)18697
Sigma 15mm F2.8 FISHEYE	18405			(F)18715
Sigma 15-30mm F3.5-4.5 EX DG	18405	18460	18482	(Z)18698
Sigma 17-70mm F2.8-4.5 DC MACRO	18405	18453	18482	(Z)18716
Sigma 50mm F2.8 EX MACRO	18426			(F)18701
Tokina 10-17/3.5-4.5 DX fisheye zoom	18405	18456	18480	(Z)18717

Nikon Type 2 LENS PORT/ GEAR CHART

For Nikon D300, D200 & D80

Camera Lens	18407 9.25" dome		18405 8" dome Port		18409 6" dome port		Zoom (Z) or Focus (F) GEAR
	EXTENSION		EXTENSION	Dome Shade	EXTENSION	Dome Shade	
Nikon 10,5mm f/2,8 G Ed AF DX	Not required		Not required	18480	Not required	18484	(F)18699
Nikon 14mm f/2.8D ED AF	18462		18456	18480	NR		(F)18693
Nikon 16mm f/2.8 D AF	Not needed		Not needed	18480	Not needed	18484	(F)18689
Nikon 18mm f/2.8 AF	18456		18456	18482	NR		(F)18680
Nikon 20mm f/2.8 AF	Not needed		Not needed	18482	Not needed	18484	(F)18674
Nikon 24mm f/2.8 D AF	Not needed		Not needed	18482	Not needed	18484	(F)18686
Nikon 28mm f/2.8 D AF	Not needed		Not needed	18482	Not needed	18484	(F)18686
Nikon 12-24mm f/4G IF-ED AF-S DX	18453		18463	18480	NR		(F)18695/(Z)18696
Nikon 14-24mm f/2.8G ED AF-S NIKKOR (*2)	18458		18458	18480	NR		(Z) 18722
Nikon 17-35mm f/2,8D IF-ED AF-S	18457		18457	18482	NR		(Z)18690
Nikon 17-55MM f/2.8 ED-IF	18457		18457	18482	NR		(Z)18711
Nikon 18-35mm f/3.5-4.5 D IF ED AF	18453		18453	18482	18453	18484	(Z)18694
Nikon 18-55mm f/3.5-5.6G ED <u>VR</u>	18463		18463	18482	18463	18484	(Z) 18721
Nikon 18-55mm f/3.5-5.6G ED II	18463		18463	18482	18463	18484	(Z) 18718
Nikon 18-70mm f/:3,5-4,5 G ED (*1)	18453		18453	18482	18462	18484	(Z)18696
Nikon 20-35mm f/2.8 D AF (*1)	18453		18453	18482	18453	18484	(Z)18675
Nikon 28-70mm f/3.5-4.5 D AF (*1)	18453		18453	18482	18462	18484	(Z)18673
Nikon 28-85mm f/3.5-4.5 AF (*1)	18462		18462	18482	18462	18484	(Z)18675
Nikon 24-50mm f/3.3-4.5 D AF (*1)	18453		18453	18482	18453	18484	(Z)18673
Sigma 10-20mm F4-5.6 EX DC HSM	18453		18456	18480	18453	18484	(Z)18698
Sigma 14mm F2.8 EX ASPHERICAL HSM	18462		18462	18480	NR		(F)18697
Sigma 15mm F2.8 FISHEYE	Not needed		Not needed	18480	Not needed	18484	(F)18715
Sigma 15-30mm F3.5-4.5 EX DG	18457		18457	18482	NR		(Z)18698
Sigma 17-70mm F2.8-4.5 DC MACRO <u>HSM</u>	18462		18462	18482	18457	18484	(Z)18719
Sigma 17-70mm F2.8-4.5 DC MACRO	18462		18462	18482	18457	18484	(Z)18716
Tokina AT-X 10-17mm F3.5-4.5 AF DX fisheye	18456		18456	18480	18463	18484	(Z)18717
Tokina AT-X 12-24mm F4 AF PRO DX	18453		18453	18480	NR		(Z)18422

NR = This lens not recommended for use with this port

(*1) +3 diopter needed for 8" dome port & a +4 diopter needed for 6" dome port

(*2) Older pre 2008 port may not fit due to the oversized nature of this lens.

Macro lenses	Port 18428 Auto Focus only	Port 18426 Auto & manual focus	For use with port 18426 only
60mm F2.8 AF (*3)	Not needed	Not needed	(F)18670/(*)3)18682
105mm F2.8 AF (*4)	18462	18462	(F)18679/(*)4)18683
105MM f/2.8 G ED-1F AF-S <u>VR</u> , NEW	18453	18453	(F)18712
200mm F4 D AF	18454	18454	(F)18656
70-180 mm f/4.5-5. 6D ED AF	18454	18454	(F)18691/(Z)18692
Sigma 50mm F2.8 EX MACRO	Not needed	Not needed	(F)18701

(*3) Auto/manual focus selector available 18682

(*4) Auto/manual focus selector available 18683



Nikon Type 3 LENS PORT/ GEAR CHART

For Nikon D3 Full Frame camera

Camera lens	18407 9.25" dome		18405 8" dome Port		18409 6" dome port		Zoom (Z) or Focus (F) GEAR
	EXTENSION		EXTENSION	Dome Shade	EXTENSION	Dome Shade	
14mm f/2.8D ED AF	18462		18456	18480	NR		(F)18693
16mm f/2.8 D AF	Not needed		Not needed	18480	Not needed	18484	(F)18689
18mm f/2.8 AF	18456		18456	18482	NR		(F)18680
20mm f/2.8 AF	Not needed		Not needed	18482	Not needed	18484	(F)18674
24mm f/2.8 D AF	Not needed		Not needed	18482	Not needed	18484	(F)18686
28mm f/2.8 D AF	Not needed		Not needed	18482	Not needed	18484	(F)18686
14-24mm f/2.8G ED AF-S NIKKOR (*2)	18458		18458	18480	NR		(Z) 18722
17-35mm f/2,8D IF-ED AF-S	18457		18457	18482	NR		(Z)18690
18-35mm f/3.5-4.5 D IF ED AF	18453		18453	18482	18453	18484	(Z)18694
18-70mm f/:3,5-4,5 G ED (*1)	18453		18453	18482	18462	18484	(Z)18696
20-35mm f/2.8 D AF (*1)	18453		18453	18482	18453	18484	(Z)18675
28-70mm f/3.5-4.5 D AF (*1)	18453		18453	18482	18462	18484	(Z)18673
28-85mm f/3.5-4.5 AF (*1)	18462		18462	18482	18462	18484	(Z)18675
24-50mm f/3.3-4.5 D AF (*1)	18453		18453	18482	18453	18484	(Z)18673
Sigma 14mm F2.8 EX ASPHERICAL HSM	18462		18462	18480	NR		(F)18697
Sigma 15mm F2.8 FISHEYE	Not needed		Not needed	18480	Not needed		(F)18715
Sigma 15-30mm F3.5-4.5 EX DG	18457		18457	18482	NR		(Z)18698
NR = This lens not recommended for use with this port							
(*1) +3 diopter needed for 8" dome port & a +4 diopter needed for 6" dome port							
(*2) Older pre 2008 port may not fit due to the oversized nature of this lens.							
Macro lenses	Port 18428 Auto Focus only		Port 18426 Auto & manual focus			For use with port 18426 only	
60mm F2.8 AF (*3)	Not needed		Not needed			(F)18670/(*)18682	
105mm F2.8 AF (*4)	18462		18462			(F)18679/(*)18683	
105MM f/2.8 G ED-1F AF-S VR, NEW	18453		18453			(F)18712	
200mm F4 D AF	18454		18454			(F)18656	
70-180 mm f/4.5-5. 6D ED AF	18454		18454			(F)18691/(Z)18692	
Sigma 50mm F2.8 EX MACRO	Not needed		Not needed			(F)18701	
(*3) Auto/manual focus selector available 18682							
(*4) Auto/manual focus selector available 18683							